


FZ scale cable configuration


Standard scale cable length { FZ620Ex ~ FZ200K1GEx : 1m
FZ150K1GFEx ~ FZ300K1GFEx : 5m

(scale cable = cable between weighing cell and indicator)

Standard configuration



Optional extension : up to 30m (per 5m)



FZ power supply cable configuration

Standard power supply cable length : 5m for all models

(power supply cable = cable between indicator and power supply box)

Standard configuration



Standard scale
cable (5m)

Power supply box



Optional extension : up to 70m (per 5m)



Replacement with option cable

Power supply box



[Important] Standard cable must be replaced with option cable,
not additionally connected to standard cable.